

## Installation Guide for Ram 2500 6.4L PNs 140801, 140801BC



\*\*\*\*\* Please compare the parts in the box with the bill of materials provided \*\*\*\*\*  
(view the following pages) to assure that you have all the parts necessary for this installation.

These instructions have been written to help you with the installation of your Borla Performance System. Please read this document completely before beginning the installation of your system.

To ensure this part number fits your specific model year, please visit our website for the latest model year listings at [www.BORLA.com](http://www.BORLA.com)

Thank you for purchasing a Borla Performance exhaust system.

This Borla Performance exhaust system (PNs 140801, 140801BC) is designed for the Ram 2500, equipped with a 6.4L V8 gasoline engine, 2WD/4WD, automatic transmission.

Borla Performance Industries recommends that an exhaust shop or professional after market parts installer, who has all the necessary equipment, tools and experienced personnel needed for proper installation, should perform the installation of this system. However, if you decide to perform the installation, we recommend someone should help you. Ensure the installer uses all under car safety precautions including eye protection.

*Please take time to read and understand the following...*

By installing your Borla Performance exhaust system, you indicate that you have read this document and you agree with the terms stated below.

It is the responsibility of the purchaser to follow all installation instruction guidelines and safety procedures supplied with your Borla Performance exhaust system.

Borla Performance Industries assumes no responsibility for damages occurring from misuse, abuse, improper installation, improper operation, lack of responsible care, or all previously stated reasons resulting from incompatibility with other manufacturer's products and/or systems.

Included with your Borla Performance exhaust system is a warranty card. Please read it carefully before you begin any work on your vehicle. If you should have any questions regarding our warranty policy, installation, or any other matter pertaining to your new Borla Performance exhaust system, please give us a call at the number provided on the warranty card.

**Minimum Required Tool List:**


**TOOLS:**

1. 3/8" drive ratchet
2. 3/8" drive extension 3"
3. 15mm socket
4. 13mm socket
5. Pry bar

**SHOP SUPPLIES:**

1. Spray lubricant

**Borla Performance - Bill of Materials**



ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	1	57145	MUFFLER ASSEMBLY
2	1	620608	OVER-AXLE PIPE Ø3.50" x 29.15" x 0.065"
3	1	57160	TAILPIPE ASSEMBLY
4	3	90122	S/S ACCUSEAL CLAMP Ø3.50



BORLA PERFORMANCE INDUSTRIES

500 Borla Drive

Johnson City TN, 37604-7523

805-986-8600

## Original Exhaust System Removal

1. Lubricate all hangers, rubber isolators, bolts and nuts.
2. Loosen the clamp securing the tailpipe assembly to the front muffler assembly.
3. Remove the tailpipe assembly hanger from its rubber isolator.
4. Loosen the clamp securing the muffler assembly to the factory extension pipe.
5. Remove the front muffler assembly hangers from their rubber isolators.
6. Remove the ground strop from the front muffler assembly.
7. Carefully remove the muffler assembly from the vehicle.
8. Original exhaust system removed.

***Caution!!! Never work on a hot exhaust system. Serious injury in the form of burns can result If the vehicle has been in use and the exhaust system is hot, allow vehicle to cool for at least 1 hour. Always wear eye protection when working under any vehicle.***

***Note: It is our recommendation that you use a hoist or hydraulic lift to facilitate the installation of your new Borla Performance Exhaust System.***


***Taking all under car safety precautions, lift the vehicle using a hoist or hydraulic lift. Once this has been done, you may begin the removal of your old exhaust system from your vehicle.***

***Note: Before removing the original exhaust system from your vehicle, please compare the parts you have received with the bill of materials provided on the previous page to assure that you have all the parts necessary for the installation of your new Borla Performance Exhaust System.***

***Note: With a used vehicle, we suggest a penetrating spray lubricant to be applied liberally to all exhaust fasteners and allowing a significant period of time for the chemical to lubricate the threads before attempting to disassemble.***

## Borla Performance Cat-Back™ Exhaust System Installation

1. Orient the components on the shop floor according to the page-2 bill of materials.
2. Place a clamp over the inlet of the muffler assembly and connect it to the factory front pipe. Do not tighten the clamp yet.
3. Insert the three (3) muffler assembly hangers into their rubber isolators.
4. Place a clamp over the inlet of the over-axle pipe and connect it to the outlet of the muffler assembly. Do not tighten the clamp yet.
5. Place a clamp over the inlet of the tailpipe assembly and connect it to the outlet of the over-axle pipe. Do not tighten the clamp yet.
18. Check your exhaust system for proper clearance under the vehicle and also for tip alignment. Starting at the front flanges and moving to the rear of vehicle, tighten the flange hardware/bolts. Orient the position of bolt (on supplied clamps) between (not over) pipe notches and tighten to 35 ft. lbs. torque.
19. Align tips and tighten hardware. Loosen clamps to rotate or slide pipe for better alignment.
20. Before starting your vehicle, make sure to check all wires, hoses, brake lines, body parts and tires for safe clearance from the exhaust system.
21. Start the vehicle and check for any leaks. If any leaks are found, determine cause (such as loose or incorrectly positioned clamp) and repair as necessary.



**WARNING:** Use extreme caution during installation. Torque all fasteners according to manufacturer's torque values and tightening sequence. **DO NOT** use air impact tools to tighten fasteners on Borla Performance Exhaust Systems. Use of such tools may result in bent flanges or gasket contact areas leading to exhaust leaks.

**NOTE:** When you first start your vehicle after the installation of your new Borla Performance Exhaust System, there may be some smoke and fumes coming from the system. This is a protective oil based coating used in the manufacturing of mandrel bent performance exhaust tubing. This is not a problem and will disappear within a very short period of time after the exhaust has reached normal operating temperatures.